## Compatibility with Windows OS

Compatibility with	vvindows	s OS							
2/20/2023									
[Note]									
<ul> <li>Please note that we have discontinue</li> </ul>	d our eupport for	any producte not	lieted in these chr	urte					
We have tested all products with the I     You can download the latest versions	latest versions as	of February 2023		ii to.					
[Note for applications that have been rel									
These are not compatible with Modern     These are not compatible with Window	n UI.		(UWP).						
	T		Winds	Windows 10		ows 10	Windows 11	Windows 11	
os	Windows 8.1		Version 21H2		Version 22H2		Version 21H2	Version 22H2	Remarks
Product Name									
	(32-bit ) Support (64-bit ) Suppor		t (32-bit ) Support (64-bit ) Support		(32-bit ) Support	(64-bit ) Support	Support (64-bit ) Support	(64-bit ) Support	
Driver									
VOX USB-MIDI Driver	Yes*1	Yes*1,*2	Yes*1	Yes*1*2	under examination	under examination	Yes*1*2	under examination	*1: Please use the latest version. *2: A 64-bit application and a 32-bit application cannot use the same MIDI IN port simultaneously.
VOX BLE-MIDI Driver	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes*1	Yes*1	*1: Use of multiple BLE-MIDI devices or multiple MIDI applications is not supported.
VOX 2ch Audio Driver	Yes*1	Yes*1	Yes*2	Yes*2	Yes*2	Yes*2	Yes*2	Yes*2	*1: Please use VOX 2ch Audio Driver version 2.0.0. *2: Please use the latest version.
			1						"2: Please use the latest version.
Software JamVOX							T T	T T	
- Software	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: To download the latest version, you can either navigate to www.jamvox-online.com or utilize the auto-update function within the
- JamVOX Monitor	Yes	Yes		End Of Support				End Of Support	JamVOX software.
Tone Room	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Please install the latest version of VOX BLE-MIDI Driver when connecting with Bluetooth MIDI.
Amp/Effector									
ToneLab ST	Т	1	1	1	T	1	I	I	
- Main Unit (USB-Audio)	Yes*1	Yes*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: It perform in the standard USB-Audio driver. It does not work with 64-bit applications.
- Main Unit (USB-MIDI)	Yes*1	Yes*1	End Of Support			End Of Support	End Of Support	End Of Support	*1: You need to install the VOX USB-MIDI Driver.
- ToneLab ST ASIO Driver - Sound Librarian	Yes Yes*1	No Yes*1	End Of Support	End Of Support End Of Support	End Of Support	End Of Support End Of Support	End Of Support End Of Support	End Of Support End Of Support	*1: You need to install the VOX USB-MIDI Driver.
ToneLab EX	105 1	165 1	End Or Support	End Of Support	End Of Support	Elia Oi Support	End of Support	End of Support	1. Too freed to miscall the VOX OSD-WILDI Driver.
- Main Unit (USB-Audio)	Yes	Yes	End Of Support			End Of Support	End Of Support	End Of Support	
Main Unit (USB-MIDI)     ToneLab EX ASIO Driver	Yes*1 Yes	Yes*1 Yes	End Of Support End Of Support		End Of Support	End Of Support End Of Support	End Of Support End Of Support	End Of Support End Of Support	*1: You need to install the VOX USB-MIDI Driver.
- Sound Librarian	Yes*1	Yes*1		End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: You need to install the VOX USB-MIDI Driver.
VX II									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
VT20X/VT40X/VT100X									
- Main Unit (USB-MIDI) VX50 GTV	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-Audio)	Yes	Yes	under	Yes	Yes	Yes	Yes	Yes	
			examination						
- Main Unit (USB-MIDI) Adio GT/BS	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-Audio)	Yes	Yes	under	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	examination Yes	Yes	Yes	Yes	Yes	Yes	
Adio Air GT/BS	res	res	res	res	res	res	168	res	
- Main Unit (USB-Audio)	Yes	Yes	under	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	examination Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (Bluetooth Audio)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (Bluetooth MIDI)	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	Yes*1,*2	*1: Bluetooth low energy compatible system is required. *2: Please install the latest version of VOX BLE-MIDI Driver for Windows.
VOX Cambridge50									
- Main Unit (USB-Audio)	Yes	Yes	under examination	Yes	Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
VOX MINI SUPERBEETLE AUDIO - Main Unit (Bluetooth Audio)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Keyboard									<u> </u>
VOX Continental									
- Main Unit (USB-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Audio Interface									
	T ,		under			· ·			
amPlug I/O	Yes	Yes		Yes	Yes	Yes	Yes	Yes	